



SOHO HDD · USB · SD Series Duplicator

Quick Start Guide

Interface Description




START



1 Plug in the power supply and turn on the power switch on the back.

1

2



2 Insert the master disk into the SOURCE port and the target disk into the Target port.

COPY

3 Press the Copy button on the touch screen to begin copying

3

4



4 The green LED light will flash during the copy process. Upon completion, the green LED light will remain steady. If an error has occurred, the LED light will be a steady red instead.



COMPARE



ERASE



FORMAT

5 Select other Function from the touch screen to start a different function.

5

Completed



- ※ **Warning**
1. **DO NOT** plug and unplug from duplicator during the execution process. It may cause damage to the duplicator system and SSD.
 2. The capacity of the target disk should be equal to or bigger than the source disk capacity.