
SOHO NVMe

Touch Duplicator Ouick Start Guide

SOURCE START **COPY NVMe** Press the Copy button Plug in the power supply and on the touch screen to turn on the power switch on begin copying the back. All interface connectors are powered off at this time to Insert the master disk into prevent short-circuit upon the SOURCE port and the inserting an NVMe SSD. target disk into the Target port.

Interface Description





Warning 1. DO NOT plug and unplug from duplicator during the execution process. It may cause damage to the duplicator system and SSD.

2. The capacity of the target disk should be equal to or bigger than the source disk capacity.